



SCAN QR CODE

TO LEARN HOW TO USE THE DUX OX



WE BELIEVE IN REDUCING WASTE AND PRESERVING THE ENVIRONMENT. THIS PACKAGING IS RECYCLABLE. Check with your local recycling facility for best disposal.



SCAN QR CODE

To learn how we're making smarter choices for a sustainable future



SACCHETTO RACCOLTA PLAST**I**CA



CARTA RACCOLTA CARTA



PREPARING FOR INSTALLATION

Remove this card insert from inside the case

INSERTING YOUR IPAD INTO THE CASE

- A. Using the slider on the back of the case, slide the adapter down and out of the closed position, so that the USB-C tip is not in the iPad area and does not obstruct the iPad installation into the bracket. The adapter will still be connected to the bracket, it does not separate from the case
- 1. Firmly press the left hand side corners of the iPad into the left corners of the case
- 2. Firmly press the right hand side corners of the iPad into the left corners of the case
- 3. Ensure all four corners are firmly in position, and the edge of the case fits smoothly around the front outer edge of the iPad
- 4. Once the iPad is securely in the case, push the adapter back into the bracket, so the USB-C tip plugs into the iPad's USB-C port

REMOVING YOUR IPAD FROM THE CASE

- A. Using the slider on the back of the case, unplug the USB-C connector from the iPad before removing the iPad from the case. If the adapter is not unplugged before the iPad is removed, it could cause damage to the iPad or the cable when the iPad is removed from the case
- 1. Release the top right corner of the iPad by firmly pushing the corner of the case back and away from the iPad
- 2. Release the bottom right corner of the iPad by firmly pushing the corner of the case away from the iPad
- 3. The iPad will be easy to remove once the USB-C connector is unplugged and the top and bottom right corners are released from the case

WARNING

If the adapter is not moved out of the way for inserting or removing the iPad from the case, the USB-C tip could break off, damaging the case and the iPad.


CHARGING THE IPAD

Insert one end of a USB-C charging cable (not included) into a power source (not included) and the other end into the USB-C port on the adapter. iPad charging level is indicated on the top right corner of the iPad screen.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

will not occur in a particular installation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference



- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help. The device has been evaluated to meet general RF exposure statement. The device can be used in portable exposure conditions without restriction.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.